

Axial Fan

Models AESⅡ / APKⅡ / APK5 / APK-B

Note



Thank you for purchasing a TERAL Fan.

Do not operate, maintain, or inspect the fan until you have read and fully understood this instruction manual.

Retain this manual where it can be consulted at any time of operation, maintenance and inspection of the fan.

To whom is performing the utility work:

Please submit this manual to the customer performing the operation, maintenance and inspection of the fan.

Limited warranties

1. In the event of failure or breakage under proper use of the product during the warranty period, equipment supplied by TERAL INC. will be repaired or replaced free of charge within the scope of the relevant part, provided that such failure or breakage is attributable to inadequacy of the design or workmanship of the equipment.
2. The warranty mentioned in the above clause shall be only the mechanical warranty of the defective part, and shall not cover any expenses or other damage arising from the failure or breakage.
3. In the event of the following failures and breakage, the costs of the repairs shall be for the account of the user.
 - (1) Failures and breakage attributable to equipment that was not delivered by TERAL INC.
 - (2) Failures and breakage after the expiration of the warranty period
 - (3) Failures and breakage caused by disasters or force majeure, such as fire, acts of God or earthquakes
 - (4) Failures and breakage resulting from repairs or modifications made without the consent of TERAL INC.
 - (5) Failures and breakage when parts other than those designated by TERAL INC. are used
4. TERAL INC. shall not be liable for the damage caused by incorrect or reckless use of the fan. Cost and expenses incurred for sending engineer(s) in such a case shall be borne by the user.
5. If the cause of the failure is unclear, necessary actions shall be determined through mutual consultation.

Purpose of this manual

The purpose of this manual is to provide the user with detailed information necessary to properly operate, maintain and inspect the fan.

This manual contains the following information and is intended for persons experienced in the operation of fans, or for those who have been trained by such experienced persons. Only qualified personnel such as electrical engineers are allowed to carry out the electrical wiring work.

Contents

Limited warranties	I
Purpose of this manual	II
Contents	II
1. Safety precautions	
1.1 Types and meanings of safety terms and graphic symbols	1-1
1.2 Safety precautions	1-1
1.3 Location of the warning labels	1-4
2. Configuration and overview of the fan	
2.1 Structure and part names of the fan	2-1
2.2 Specifications and accessories of the fan	2-2
3. Transportation and installation	
3.1 Before using the fan	3-1
3.2 Precautions during transportation and storage	3-1
3.2.1 Precautions for transportation	3-1
3.2.2 Precautions for storage	3-2
3.3 Precautions for the location of installation	3-2
3.4 Foundation	3-2
3.5 Installation	3-3
3.5.1 Floor type	3-3
3.5.2 Ceiling mounted type	3-4
3.5.3 Vibration-proof, earthquake-resistant type	3-4
3.6 Alignment (APKII. APK5. APK-B)	3-5
3.7 Precautions for connecting the ducts	3-7
3.8 Precautions for wiring work	3-8
4. Preparation for operation	
4.1 Points to be checked before test running	4-1
4.1.1 Checking the electrical system	4-1
4.1.2 Checking the fan system	4-1
4.1.3 Precautions for inverter operation	4-1
4.2 Test operation	4-2
4.2.1 Precautions during startup	4-2
4.2.2 Precautions during operation	4-3
4.2.3 Precautions for stopping the operation	4-3
5. Long-term shutdown	
5.1 Precautions for long-term shutdown	5-1
6. Maintenance and inspection	
6.1 Daily inspection	6-1
6.2 Periodic inspection	6-2
6.2.1 Greasing and replacement of the bearings	6-4
6.2.2 Consumables	6-4
7. Troubleshooting	
7.1 Troubleshooting	7-1
8. Special accessories	
8.1 Dampers	8-1
8.2 Expansion joint	8-1
8.3 Filter	8-1

1. Safety precautions

1.1 Types and meanings of safety terms and graphic symbols

This instruction manual divides precautions into the following four categories according to the level of hazards (or the severity of the accident). Be sure to understand the meanings of the following signs and comply with the content (instructions) of the instruction manual.

■ Explanation of warnings

Safety sign	Meaning
 Danger	Indicates an imminently hazardous situation. Failure to observe this will result in death or serious injury.
 Warning	Indicates a potentially hazardous situation. Failure to observe this will result in death or serious injury.
 Caution	Indicates a potentially hazardous situation. Failure to observe this will result in minor or moderate injury or property damage.
 Note	Indicates information that is in particular to be noted or emphasized.

■ Explanation of the graphic symbols

				
Don'ts	Do not touch	Do not disassemble	Do not touch with wet hand	Do not expose to water
These graphic symbols indicate prohibited actions (that must NOT be done).				
	This graphic symbol indicates mandatory actions (that must be done).			
Do's				
				
Caution	Electric shock hazard	Rotation hazard	Hot surface	
These graphic symbols indicate existing hazards to beware of.				

1.2 Safety precautions

 Warning	
 Instruct the vendor to move and carry the fan in consideration of the center of mass and its weight. Otherwise, the fan may fall, thus leading to an injury or damage.	 Do not carry out any work with/on the fan that is being lifted. Otherwise, the unit may fall, thus leading to an injury or damage.
 Before hoisting the fan, refer to the catalog, dimensional outline drawing, and other documents to check the weight of the units. Do not hoist any unit if its weight exceeds the rated load of the hoisting equipment/devices. Otherwise, the fan may fall, thus leading to an injury or damage.	 Do not hoist the whole unit using the main shaft of the fan, the eyebolt on the motor, or any other parts not intended for the purpose. Otherwise, the unit may be damaged.
 Only those who are authorized by the site manager are allowed to operate the fan. Operation by unskilled personnel may lead to an unforeseen accident.	 Installation, maintenance, and inspection must only be carried out by personnel who have been trained to handle the fan. Operation by unskilled personnel may lead to an unforeseen accident.
 Only qualified personnel, such as licensed electrical engineer, is allowed to carry out electric work. Otherwise, it may lead to an electric shock, fire, failure, or other problems.	 Use high-quality wiring equipment and devices, and carry out wiring work safely and securely according to the technical standards for electrical facilities, as well as the indoor wiring regulations. Otherwise, it may lead to an electric shock, fire, or other problems.
 Do not connect the ground wire to a gas pipe, water pipe or lightning rod. Such a connection is illegal and leads to an electric shock, explosion, or fire.	 Securely install the ground wire and ensure to carry out grounding work. Otherwise, it may lead to an electric leak or electric shock.
 Do not operate the fan if abnormal condition is observed in any operation, movement, parts, etc. Otherwise, it may lead to an injury, failure, or various accidents.	 Correctly and securely connect the wires according to the wiring diagram within the terminal box and the instruction manual. Incorrect wiring may cause a fire, electric shock, failure, or other problems.

 Warning	
 Be sure to keep the terminal box cover attached before turning on the power. Otherwise, it may lead to an electric shock.	 Be sure to install a belt guard, bearing guard, and coupling cover during running the fan. Otherwise, it may lead to an injury or damage.
 The main shaft, impeller, V-belt pulley, and V-belt are rotating during operation. Be extra careful not to get your clothes or other parts caught in these parts. Otherwise, it may lead to an injury or damage.	 Do not forcibly bend, pull, or pinch the power cable or any lead wires of the product. Otherwise, it may lead to an electric shock or fire.
 Check the wiring sections and wires for any looseness. A loose connection may cause a fire or electric shock.	 Before starting the maintenance or inspection work, be sure to stop the fan and turn off the main power of the panel board. Otherwise, it may lead to an electric shock, injury, damage, or leakage.
 Before starting the fan or carrying out maintenance/inspection work, ensure that all the relevant workers are informed of the operation and that there are no workers in the dangerous zone. Otherwise, it may lead to an unforeseen accident.	 Before rotating the fan shaft by hand to check its smooth rotation, be sure to turn off the main power. Otherwise, it may lead to an injury or damage.
 After turning on the power, do not touch the fan other than those required for operation. Otherwise, it may lead to an electric shock or injury.	 Be sure to install a protective wire mesh on the suction port of the fan if it is open. Otherwise, it may lead to an injury or damage.
 If the blowing gas is hot, do not touch the fan body or ducts. Touching the hot surface may result in burns.	 Do not use it if the insulation resistance of the motor is 1MΩ or less. Otherwise, it may cause damage to the motor, electric shock or fire.
 Do not put your fingers or foreign objects into any openings or rotating part of the motor during operation. Otherwise, it may lead to an injury or damage.	 For overhaul, parts replacement, and repairs that involve disassembly, contact TERAL INC. If unskilled personnel carry out work that requires special knowledge, it may lead to an accident or failure.
 In the event of a power failure, be sure to turn off the main power supply. Otherwise, the fan may suddenly start up on restoration of the power, thus leading to an injury.	 If you leave the fan unused for a long time, be sure to turn off the main power. Otherwise, it may lead to a fire or electric shock.
 Be sure to turn off the main power before changing any wiring of the fan. Otherwise, it may lead to an electric shock or injury.	 Be sure to install a ground fault interrupter to the main power.
 Do not put your fingers or any rods into the suction port or blowout port.	 Do not place any objects around the suction port or blowout port of the fan.
 Regularly inspect your equipment and perform maintenance on each component.	 If motors or control panels are used for more than a certain period of time, it may cause ignition or other accidents due to aging deterioration.
 Electric motor or control panel insulation degradation may result in electric leakage, electric shock, or fire. Keep the ambient temperature at 0 to 40°C with sufficient ventilation to prevent damage to the equipment and deterioration of its life. Avoid dust, corrosive or explosive gases, salinity, humidity, condensation. For indoor installations avoid direct sunlight or wind and rain.	

 Caution	
 Do not use the fan outside the range of the product specifications. Otherwise, it may lead to an electric shock, fire, leakage, failure, or other problems.	 Do not use the fan at an incorrect power voltage. An incorrect voltage may damage the motor.
 Do not use a single fan unit as the only means of directly operating key facilities or sustaining life. In the event of a failure, necessary ventilation may not be performed due to malfunction. Ensure to make a backup unit available for operation.	 Before unpacking the delivered container, check that the container is placed in the correct orientation (not upside down). Carefully unpack the container, while paying special attention to nails. Otherwise, it may lead to an injury or damage.
 Do not install the fan anywhere exposed to direct flame or with any other risk of high temperature. Otherwise, it may lead to damage or fire.	 Do not install the fan in any humid places such as the bathroom. Otherwise, it may lead to damage or fire.

 Caution	
 Do not install the fan in any places where toxic gases are produced from acids, alkalis, organic solvent, paint or other substances or where corrosive gases are produced. Otherwise, it may lead to an injury or damage.	 Install the open suction port at a position far away from the exhaust vents of combustion gas and other gases. Otherwise, it may lead to damage or fire.
 Do not expose the motor to liquid. Otherwise, it may lead to an electric shock, electric leak, failure, or other problems.	 If the fan is fitted with a drain port, be sure to drain water. Water leaking through gaps may cause stains and corrosion on the equipment and surrounding areas.
 In the event of an alarm or abnormal condition that cannot be resolved, immediately stop the operation, turn off the power, and then contact For overhaul, parts replacement, and repairs that involve disassembly, contact TERAL INC. Otherwise, it may lead to an accident.	 Do not run the fan with tools or other objects placed on the unit. Otherwise, it may lead to an injury or damage.
 Check that the delivered items are exactly what you ordered. The use of a wrong product may cause an injury or failure.	 Do not place any combustibles around the product. Otherwise, it may lead to a fire.
 Check the rotation direction of the fan before connecting it to the duct. Otherwise, it may lead to an injury or damage.	 Do not place any obstacles around the product that may hinder ventilation. Otherwise, it may lead to a fire.
 The start frequency of air-conditioning fan should be once a day. Otherwise, the fan may be damaged.	
 Do not run the fan if it has any defects or faulty parts. Otherwise, it may lead to an injury or damage.	 Periodically clean the fan if dust or oil adheres to the machine. Otherwise, it may lead to an injury or damage.
 Do not use a 60Hz model in a 50Hz area. Otherwise, the specified performance cannot be obtained.	 Do not use a 50Hz model in a 60Hz area. Otherwise the fan may be damaged, and the motor may burn out.
 Be sure to install an overcurrent protection device. Installation is obligatory according to the Electrical Equipment Technical Standards. Failure to do so may result in a fire or damage to the product. It is also recommended to install a protective device such as a leakage circuit breaker.	 Do not touch any terminals or wires when measuring the insulation resistance. Otherwise, it may lead to an electric shock.
 The impeller must not be rotating in reverse when the power is turned on. Otherwise the fan may be damaged.	 Do not allow the weight of the duct system to be applied to the fan. Otherwise, it may cause vibration of the fan or damage it.
 Do not make the duct significantly thinner than the fan diameter, and do not install a curved part immediately before the duct. Otherwise, an unexpected pressure loss may occur, resulting in insufficient performance.	 Dispose of the product as industrial waste.
 When you lift the product by hand, pay attention to its weight. Do not allow a single person to lift a product heavier than 15 kg. Otherwise, it may put strain on the body, thus leading to an injury.	 Be sure to conduct inspection according to the Maintenance checklist. Otherwise, you cannot prevent potential failures, thus leading to a higher risk of accidents.

1.3 Location of the warning labels

Figure 1 shows the locations to which each warning label should be affixed. If these labels become dirty and hard to read or if they are peeled off, replace with a new one.





Figure 1 – Example of safety labels and the locations


2. Configuration and overview of the fan

2.1 Structure and part names of the fan

(1) Direct motor driven model AESII



(2) Belt driven model APKII, APK5, APK-B



No.	Part name
①	Fan casing
②	Impeller
③	Main shaft
④	Bearing
⑤	V-belt pulley
⑥	Belt guard
⑦	Suction companion flange
⑧	Discharge companion flange
⑨	Motor
⑩	Rubber vibration isolator (only for vibration insulation model)
⑪	Vibration absorber base (only for vibration insulation model)

2.2 Specifications and accessories of the fan

If you purchased a standard product, refer to the standard specifications in the following table.
For a custom-made product with special specifications, refer to the specifications including the external dimensions drawing.

 **Caution** 

Do not use the fan under any conditions other than those provided in the specifications. Otherwise, it may lead to an electric shock, fire, or failure.

(1) Standard specifications and special specifications

●: Standard specifications, ◎: Special specifications, -: Not available

Model		APK5	APK-B	APK II	AES II
Transmission method		Belt-driven	Belt-driven	Belt-driven	Motor direct-coupled
Gas temperature	0-40°C	●	●	●	●
	41-80°C	◎※ 1	-	◎※ 1	-
Structure	Pillow block	●	-	●	-
	Square flange unit	-	●	-	-
	Sealed ball bearing in motor	-	-	-	●
	Companion flange (discharge)	●	●	●	●
	Companion flange (suction)	●	●	●	●
	Inspection port	◎	◎	◎	◎
	Terminal box	-	-	-	◎
	Silencer box	◎	-	-	◎
	Vertical flange mounted	◎※ 2	◎※ 2	◎※ 2	◎※ 2
	Vertical bracket mounted	◎※ 2	◎※ 2	◎※ 2	◎※ 2
Installation method	Floor type	●	●	●	●
	With vibration isolators(floor type or ceiling mounted type)	◎	◎	◎	◎
Motor	Totally enclosed fan-cooled type	●	●	●	●
	Different voltage	◎	◎	◎	◎
Painting	Priming and inner surface: Anti-corrosive coating				
	Finish coating on external surface: Acrylic alkyd resin paint, Munsell7.5GB5/1.5	●	●	●	●
	Epoxy resin coating	◎	◎	◎	◎
	Polyvinyl chloride resin coating	◎	◎	◎	◎
	Salt resistant coating	◎	◎	◎	◎
	Specified color coating	◎	◎	◎	◎

※1: Internal clearance HR5 heat-resistant bearings are used according to temperature classification.

※2: Supported only when the bore is 125 or less and the motor output is 30kW or less.

(2) Special accessories

Special accessories	
Suction damper	Suction wire mesh
Discharge damper	Suction filter
Bolts and nuts for companion flange	Expansion joint
Packing for companion flange	Connecting pipe

3. Transportation and installation

3.1 Before using the fan

When you receive the fan, check the following points first.

If there are any problems, contact TERAL INC.

Handle the motor according to the instruction manual of the motor.

Incorrect handling may result in an accident or failure.


- (1) Check that the nameplate to verify that the unit is the one you ordered.
In particular, check the information on the rated current (50Hz or 60Hz).
- (2) Ensure that no part of the product is damaged during transportation.
- (3) Ensure that all fastening parts including bolts and nuts are securely tightened.
- (4) Check that all the accessories that you ordered have been delivered.

3.2 Precautions during transportation and storage


3.2.1 Precautions for transportation



Instruct the vendor to place the fan in consideration of the center of mass and its weight.



Before hoisting the fan, refer to the catalog, dimensional outline drawing, and other documents to check the weight of the units.
Do not hoist any units if its weight exceeds the rated load of the hoisting equipment/devices.



Do not enter the area under the suspended fan.
You may be pinned/crushed under the fan.



Pay special attention to nails when opening a wooden crate. Otherwise, you may get injured.

- (1) When you hoist the fan, ensure to keep it level using the lifting lug or eye bolts fitted with the unit.
Do not, however, hoist the whole unit using the main shaft of the fan, the eyebolt on the motor, or any other parts not intended for the purpose. Hoist the fan using appropriate hoisting equipment considering the fan's center of mass.
- (2) If it is difficult to keep the fan level, use the common base etc. when you hoist it.
- (3) If the fan is small-sized and has no lifting lug, hoist the fan by passing a rope or wire under the common base.
- (4) If the hoisting equipment comes in contact with the fan, prevent any damage by applying cloth in between or by using hoisting equipment that does not cause scratches or flaws.

Note

Any scratches or flaws on coating may cause rusting.
Ensure to carry out repair coating in such a case.

3.2.2 Precautions for storage

- (1) Do not allow rust to be formed on the product while you store it before installation.
In particular, take measures to prevent any rainwater or dust from entering the inside, particularly the bearing section, for example by covering it with a vinyl sheet.
- (2) Store indoor-type motors and other electrical devices indoors.
Also for equipment for outdoor use, protect its wiring and cable openings against moisture.
- (3) If you store the fan for over one month, remove the V-belt from the unit and avoid a hot, humid, or dusty place.
- (4) If a film is wrapped around the fan on shipment and the film is exposed to sunlight or rainwater, it may stick to the product. Pay attention to the location where you store the fan.

3.3 Precautions for the location of installation



Electric motor or control panel insulation degradation may result in electric leakage, electric shock, or fire.
Keep the ambient temperature at 0 to 40°C with sufficient ventilation to prevent damage to the equipment and deterioration of its life. Avoid dust, corrosive or explosive gases, salinity, humidity, condensation. For indoor installations avoid direct sunlight or wind and rain.

Install the fan in a place where the following conditions are satisfied:

- (1) Do not use an indoor type fan outdoors.
Ensure that the fan does not suck in any rainwater.
- (2) A well-ventilated place with minimum exposure to dust and moisture.
If you install the unit in a fully enclosed room—such as a machine room, install a ventilator so that heat generated from the motor or other sources will not increase the room temperature.
- (3) A place with an ambient temperature of 0°C to 40°C.
- (4) A place where the fan cannot be accessed or operated by unauthorized persons.
Take measures to prevent unauthorized persons from having access to the fan, for example by installing a barrier.
- (5) A place where the fan can be easily inspected and repaired.
When installing a large-size fan, secure space wide enough to place the impeller and to carry out work such as assembly, disassembly, or repair. For APKII or APK5, secure a space wide enough at least to carry out the replacement or alignment of pulleys.
- (6) If you install the fan indoors, ensure that the room has doors that are wide enough to allow the fan to pass through.
- (7) If you place a large-sized fan or if you frequently need to replace or repair a fan because of corrosion or wear on the impeller, consider using minimal hoisting equipment.



Do not place an obstacle that hinders ventilation or inflammables around the motor of APKII APK5 APK-B. They may prevent heat from escaping, thus resulting in overheating or fire.

Note

Any scratches or flaws on coating may cause rusting.
Ensure to carry out repair coating in such a case.

3.4 Foundation

- (1) The foundation must be rigid enough to bear the weight of the fan and the vibration and load caused by the rotation.
- (2) Make sure that the horizontal plane of the foundation concrete must not be changed due to ground subsidence.
If the ground is soft, reinforce it by driving piles or other methods.

- (3) The weight of the foundation must be from two to four times the fan's total weight including the motor.
- (4) Isolate the machine foundation from the pillars/floor of the building so that vibration will not be transmitted.
- (5) When installing two or more foundations, isolate each of them from others so that vibration will not be transmitted.
- (6) In a standard method, box out holes in the foundation concrete and fix the foundation bolts into the foundation when installing the fan.
Refer to the external dimensions drawing for the positions of the holes for embedding foundation bolts.
When foundation bolts are pre-embedded before the fan arrives, the bolts should be carefully positioned, using a template or other tools.
- (7) When the fan is used as construction equipment for which the foundation is installed on the 2nd or higher floor, the foundation should be positioned in line with the beams and as close to the wall of the building as possible.

3.5 Installation

3.5.1 Floor type

Carry out the following steps to install the fan using the foundation bolts (blockout method).
(Take necessary steps as appropriate when using the pre-embedded foundation bolts.)

- (1) Clean the surface of the foundation concrete and check the level.
If necessary, chip the concrete surface.
- (2) Clean the foundation bolt holes and remove dust.
The inner walls of the foundation bolt holes must be moist but water should not remain in them. Drain any water completely.
- (3) Set one 1 flat liner and two 2 taper liners symmetrically on both sides of the foundation bolt hole of the fan as shown in the figure. Insert an auxiliary liner (3 mm thickness or more) if required. If the distance between the foundation bolts exceeds 1 m, place an additional liner between them.




Figure 2 – Example of liner placement

- (4) Place the fan base or vibration absorber base on the liners, and insert the foundation bolts through the bolt holes of the fan base or vibration absorber base so that they are hung inside the blockout holes. To make the fan earthquake-resistant, weld each foundation bolt to reinforcing bars of the foundation concrete.
- (5) Adjust and fix the position and height of the fan by using taper liners.
- (6) Chip the inner walls of the foundation bolt holes to roughen them sufficiently to pour non-shrinkage mortar into the holes.
Make sure that the foundation bolts are positioned vertically at the center of the holes.
- (7) After the mortar is hardened sufficiently, fasten the nuts of the foundation bolts tightly.
At this time, ensure to tighten the nuts evenly. Use tapered washers if the fan base is made of channel steel. To prevent the liners from shifting during operation, weld them in place.
- (8) Pour an enough amount of mortar into the gap between the fan base and the foundation concrete to form a solid concrete structure.
- (9) Carefully keep the mortar from being shrunk or cracked.
Consider the installation of a drainage pit if drain line is required.
- (10) When the fan is equipped with a vibration isolation device, fix the vibration absorber base (lower base) in place with the foundation bolts. If spring vibration isolator is used for the fan that are to be used as construction equipment, lay out the vibration isolation materials evenly around the center of gravity of the fan assembly.
- (11) When you have installed the fan and properly connected the duct, carry out the alignment work for APKII, APK5, and APK-B described in the upcoming section 3.6.
Ensure that the measurement for center alignment is carried out in the state where the foundation bolts are fastened tightly.

3.5.2 Ceiling mounted type

- (1) By connecting the fan's base to the hanging bolts that are embedded in the ceiling, horizontally suspend the fan. Ensure that the load of the fan is evenly distributed among all the hanging bolts.
- (2) Be sure to use hanging bolts that are strong enough to sustain the load (in terms of the strength of the bolt itself as well as the pre-installed condition).
- (3) After you have installed the fan, lock the nut on each hanging bolt to prevent them from coming loose.
- (4) To make the fan earthquake-resistant, firmly install the fan onto a section steel frame fixed onto a building structure.
- (5) As shown in Figure 3, firmly fix the ceiling mounted vibration absorber base onto the ceiling hanging bolts. To prevent the unit from vibrating horizontally, install a vibration isolator bracket at an angle onto each ceiling hanging bolt using a continuous-thread stud, turn buckle, or other parts.




Figure 3 – Installation example of a ceiling mounting type




Figure 4 - Structure of the hanger type vibration isolator

3.5.3 Vibration-proof, earthquake-resistant type

- (1) If you use vibration isolation rubber during the installation, ensure that the upper and lower sides of the hole are positioned in a vertical line and that no part of the rubber is twisted or distorted, as shown in Figure 5.




Figure 5 – Installation example of rubber vibration isolator

- (2) The product is shipped with the stopper bolts tightened as shown in Fig. 6_ "When shipped." After installation of the product at the delivery site, be sure to fix the stopper bolts in the position shown in Fig. 6_ "After installation."




Figure 6 – Stopper bolt adjustment



If the fan is operated with the stopper bolts locked (see Figure 6), the expected vibration-proof effect cannot be obtained.

- (3) For fans of a vibration-proof, earthquake-resistant type, be sure to use expansion joints, and do not connect the fan and the duct directly.

3.6 Alignment (APKII. APK5. APK-B)

The fan is aligned at the factory before shipping, but should be realigned after installation.



Remove the belt guard and shaft coupling guard when you carry out the alignment. Before you operate the fan, however, be sure to attach them again. Do not operate the fan without the belt guard or shaft coupling guard. Failure to observe this, you may get caught into the machinery and injured.



Improper alignment may lead to machine damage, vibrations, or noise. Ensure to achieve accurate alignment.

- (1) Place a ruler or a piano wire onto the outer surfaces of the V-belt pulleys on both the fan and motor sides, and check and adjust it so that the surfaces of the pulleys are on a straight line as shown in Figure 7.
- (2) If you can depress the middle of the V-belt with your finger up to about the same depth as the thickness of the V-belt, the tension of standard V-belts is appropriate. Use the slide base of the motor to adjust the tension of the V-belt.
- (3) Make high tension V-belts slightly tighter than standard V-belts. Too loose tension may cause the belt to slip during startup, and excessive tension may apply a large load to the shaft and bearing, thus resulting in failure.
- (4) Since V-belts tend to stretch at an early stage of use, ensure to readjust the tension in the first several days of operation (about 50 hours after the start of operation). Otherwise, the belt may break prematurely or come off.




Figure 7 – Belt tension measurement

First obtain the value of deflection δ by the relationship $\delta = 0.016l$. (Where l is the distance between the pulleys) Then provide the deflection δ mm to the middle of the V-belt and adjust the tension using a tension meter so that deflection load at this point becomes the value shown in the table below.

Note

When alignment and belt tension adjustment is performed, the coating film on the sliding part near the motor mounting leg may be peeled off and rust may be generated. If you install the fan in a humid place or outdoors, apply repair coating to bolts and nuts, including the peeled areas in order to prevent rusting.




Figure 8 - How to measure the belt deflection load

For standard V-belt and Red seal type

A Type

Qty	Motor output kW	Td for each V-belt Unit : N	
		For new belt	For re-tensioning
1	0.2	9 ~ 11	8 ~ 9
	0.4	9 ~ 11	8 ~ 9
	0.75	12 ~ 14	10 ~ 12
	1.5	17 ~ 19	15 ~ 16
	2.2	21.5 ~ 23.5	18.5 ~ 20.5
2	3.7	25.5 ~ 27.5	22 ~ 24
	0.75	7 ~ 9	6 ~ 8
	1.5	13.5 ~ 15.5	11.5 ~ 13.5
	2.2	15.5 ~ 17.5	13.5 ~ 15.5
	3.7	18.5 ~ 20.5	16 ~ 18
3	5.5	22.5 ~ 24.5	19.5 ~ 21.5
	3.7	14.5 ~ 16.5	12.5 ~ 14.5

B Type

Qty	Motor output kW	Td for each V-belt Unit : N	
		For new belt	For re-tensioning
2	1.5	11 ~ 13	9 ~ 11
	2.2	14.5 ~ 16.5	12.5 ~ 14.5
	3.7	16.5 ~ 18.5	14.5 ~ 16.5
	5.5	21.5 ~ 23.5	18.5 ~ 20.5
	7.5	27.5 ~ 29.5	23.5 ~ 25.5
	11	33.5 ~ 35.5	28.5 ~ 30.5
3	15	42 ~ 44	36.5 ~ 38.5
	5.5	19.5 ~ 21.5	17 ~ 19
	7.5	23.5 ~ 25.5	20 ~ 22
	11	30.5 ~ 32.5	26 ~ 28
	15	35.5 ~ 37.5	30.5 ~ 32.5
4	18.5	39 ~ 41	34 ~ 36
	15	29.5 ~ 31.5	25.5 ~ 27.5
	18.5	33.5 ~ 35.5	28.5 ~ 30.5
	22	35.5 ~ 37.5	30.5 ~ 32.5
4	30	43 ~ 45	37 ~ 39

For narrow V-belts

3V Type

Qty	Motor output kW	Td for each V-belt Unit : N	
		For new belt	For re-tensioning
2	2.2	10 ~ 12	8 ~ 10
	3.7	14.5 ~ 16.5	12.5 ~ 14.5
	5.5	17.5 ~ 19.5	15 ~ 17
	7.5	19.5 ~ 21.5	17 ~ 19
	11	23.5 ~ 25.5	20 ~ 22
	15	28.5 ~ 30.5	24.5 ~ 26.5
3	5.5	12.5 ~ 14.5	11 ~ 13
	7.5	17.5 ~ 19.5	15 ~ 17
	11	19.5 ~ 21.5	17 ~ 19
	15	22.5 ~ 24.5	19.5 ~ 21.5
	18.5	23.5 ~ 25.5	20 ~ 22
4	11	14.5 ~ 16.5	12.5 ~ 14.5
	15	18.5 ~ 20.5	16 ~ 18
	18.5	22.5 ~ 24.5	19.5 ~ 21.5
4	22	22.5 ~ 24.5	19.5 ~ 21.5

5V Type

Qty	Motor output kW	Td for each V-belt Unit : N	
		For new belt	For re-tensioning
2	11	31.5 ~ 33.5	27 ~ 29
	15	39 ~ 41	34 ~ 36
	18.5	44 ~ 46	38 ~ 40
	22	56 ~ 58	48 ~ 50
	30	67.5 ~ 69.5	58.5 ~ 60.5
	15	29.5 ~ 31.5	25.5 ~ 27.5
3	18.5	33.5 ~ 35.5	28.5 ~ 30.5
	22	40 ~ 42	34.5 ~ 36.5
	30	55 ~ 57	47.5 ~ 49.5
	37	61.5 ~ 63.5	53.5 ~ 55.5
	45	72.5 ~ 74.5	62.5 ~ 64.5
	55	76.5 ~ 78.5	66 ~ 68
4	30	45 ~ 47	39 ~ 41
	37	51 ~ 53	44 ~ 46
	45	59 ~ 61	51 ~ 53
	55	67.5 ~ 69.5	58.5 ~ 60.5

3.7 Precautions for connecting the ducts



Caution

Ensure not to apply the weight of the duct on the fan.
Otherwise, failure, breakage, or vibration may be caused.

- (1) Connect the flange of the fan and the duct via an expansion joint so that vibration and noise would not be transmitted outside.
- (2) Before connecting the ducts, check inside the ducts and fan, and remove any foreign matter, such as waste cloth and tools.



Warning



Be sure to install a protective wire mesh on any open air intakes of the fan.

- (3) To prevent foreign matter from being sucked in, install a protective wire mesh to the duct inlet or the air intake of fan where air is sucked directly. If dust or water can enter into the fan, install a filter to prevent it.
- (4) If an inactive (not running) fan is exposed to air in the reverse direction, it rotates in reverse. Avoid exposure to such air because it takes longer to start a fan that is rotating in reverse.
- (5) In general, unexpected pressure loss may occur due to the connection to (a) ducts that are much smaller than the port diameter of the fan, (b) ducts with a series of bends, or (c) ducts with bends just before or after the connection to the fan.
- (6) If air is directly suctioned from the intake of the fan, a turbulent air flow may degrade performance and/or cause noise. Install a bell mouth or provide an appropriately long and straight tube on the suction side of the fan.
- (7) If the intake air is swirling, install guide vanes or increase the radius of the bends. The shape of the suction chamber must be taken into consideration as well.

Note

If there is a wall in front of the fan suction port, provide a clearance of at least the size of the port between the suction port and the wall.




Figure 9 Examples of duct installation

3.8 Precautions for wiring work



Use high-quality wiring equipment and devices, and carry out wiring work safely and securely according to the technical standards for electrical facilities, as well as the indoor wiring regulations.
Only qualified personnel such as licensed electrical engineers are allowed to carry out electrical wiring work. Unqualified persons are prohibited by law to carry out wiring work, and it is very dangerous.

- (1) Be sure to install a ground fault interrupter and an overload protection device on the primary side of the fan.

In case that a thermal relay is used as an overload protection device, the fan may trip at a start-up due to its starting characteristics.

*The starting current of premium efficiency (equivalent to IE3) motors may become higher than that of standard efficiency (IE1) motors. Therefore, it is necessary to verify the applicability of its ground fault interrupter and overload protection device.

If you have any questions, contact TERAL INC.



Do not push the motor connection cable into the casing, bend it, pull it forcibly, or pinch it.
Failure to observe this may result in an electric shock.

- (2) Be sure to install a ground wire to prevent an electric shock.
- For APK II, APK 5, and APK-B, connect the ground wire to the ground terminal inside the terminal box of the fan.
 - Do not connect the ground wire to gas pipes, water pipes, lightening arresters, or ground wires for telephone.



It is prohibited by law to perform incomplete wiring work, which exposes personnel to a great danger.

- (3) Refer to Figure 10 for connection patterns.
- (4) For AESII, connect the cable to the terminal in the motor terminal box and pull it out of the fan.
Standard connections are direct-start for 7.5kW or smaller motors and Star-Delta starting for 11kW or larger motors.
Connect the cable and power supply according to the instruction manual of the motor.
- (5) Control the fluctuation of the voltage within $\pm 10\%$ of the rated voltage, and the frequency within $\pm 5\%$ of the rated frequency. If the product is not used within the range, it may break down.
- (6) Before running the fan, check the following points again:
- ① An appropriate fuse (ground fault interrupter) is installed.
 - ② Wiring is correct.
 - ③ The product is securely connected to a ground.
 - ④ None of the three terminals of the motor has come loose or is disconnected.

Number of terminals	3	6		12
Connection pattern	Direct on line Terminal block type	Direct on line Terminal block type	Direct on line Lug terminal type	Direct on line 400 V class 200 V class Lug terminal type
		Star-delta starting Terminal block type	Star-delta starting Lug terminal type	Star-delta starting 400 V class 200 V class Lug terminal type

* The above connection patterns cause the motor to run counterclockwise when viewed from the shaft end of the motor.

If you need to run the motor in reverse direction, reverse the connections to R and T terminals of the power wires.

Figure 10 – Connection patterns of the motor terminals

4. Preparation for operation


4.1 Points to be checked before test running

4.1.1 Checking the electrical system

- (1) Check that the fan is correctly wired.
- (2) Check the frequency.
Running the fan at a frequency other than the specifications may reduce its performance, burn out the motor, or damage the impeller and main shaft.
- (3) Check the terminals for any loose connection.
- (4) Check that the unit is securely grounded.
- (5) Check that the setup value of the overload protection device is consistent with the rated current value of the motor.
The rated current is indicated on the motor nameplate for APKII, APK5 and APK-B, and on the fan nameplate for AESII.

4.1.2 Checking the fan system

- (1) Check that water has not accumulated in the fan and that no foreign objects or materials such as tools have been left inside.
- (2) Check that all foundation bolts and the connections on the fan, accessories and pipe joints are securely tightened.
- (3) Check that the dampers and valves can fully open and close, and that they operate normally.
- (4) For APKII, APK5 and APK-B, check the alignment of V-belt pulleys and the tension of V-belt.
- (5) Rotate the fan by hand or by inching a motor to check that it can rotate smoothly without any internal obstructions.



Before turning the fan shaft by hand to check its rotation, be sure to turn off the main power.

- (6) Place an operator in advance so that the fan can be turned OFF immediately after the instructions of the person in charge of the operation.



Do not operate the fan if you notice any abnormal condition such as abnormal noise. Be sure to contact TERAL INC.

4.1.3 Precautions for inverter operation

- (1) If you use the fan with an inverter, please let us know before placing an order.
Inverter operation may not be possible with some standard motors.
- (2) The initial settings of off-the-shelf inverters are not tailored for running the fan.
The use of the inverter at its initial settings may cause abnormal vibration or damage of the fan.
Be sure to make the settings of the inverter before operation, referring to the following information. Changing the inverter settings may solve some abnormal condition.

<Inverter setup values (for reference only)>

- ① Base frequency : Set this to the specified frequency (indicated on the nameplate)
- ② Maximum frequency : Set this to the specified frequency (indicated on the nameplate)
- ③ Maximum output voltage : Set this to the rated voltage of the motor.

- ④ Upper limit frequency : Set this to the specified frequency (indicated on the nameplate)
- ⑤ Lower limit frequency : Set this to a value between 25 Hz and 30 Hz. Running the fan at a lower frequency may cause the motor to stall or generate heat or may make the inverter output unstable.
- ⑥ V/F characteristics : Set this to square reduction torque.
- ⑦ Acceleration / deceleration time : Set this to a value between 30 and 40 seconds. Starting/stopping the fan in a shorter period may trip the inverter.
- ⑧ Carrier frequency : The factory settings of the carrier frequency depend on the manufacturer.
If the fan produces any abnormal vibration or noise with the current settings, the problem may be solved by changing the carrier frequency setting according to the following table.

Carrier frequency	Low	-	High
Noise from the motor (high-pitched noise)	Loud	-	Small
Noise from the inverter	Small	-	Loud
Number of times surge voltage is applied	Few	-	Frequent

- (3) When using the fan with an inverter, check during test operation that the fan runs normally at all the frequencies used. Running the fan under abnormal conditions such as abnormal vibration may damage the fan.
To avoid abnormal vibration, jump the resonance frequency of eigenvalues of the fan, motor, fan + foundation, etc. by setting the inverter.

4.2 Test operation

4.2.1 Precautions during startup

 **Warning** 

If your fan comes with a belt guard, be sure to attach the belt guard before operation.

- (1) Close the damper and turn the power switch ON and OFF once or twice to check for any abnormal operating condition such as abnormal noise or vibration. Also check the rotation direction of the fan at that time.
If the fan rotates in the opposite direction, swap two of the three wires of the power supply connections.


 **Warning** 

Be sure to turn off the main power before changing any wiring of the fan.

- (2) Turn on the power, and monitor the unit closely until it reaches its maximum speed. At that time, check for any abnormal noise, vibrations, current, or other abnormal conditions.
- (3) Proceed with continuous operation, and gradually open the damper.
In order to check the condition of each part, keep the fan running at a low flow rate (light load) for 20 to 30 minutes. At that time, ensure that the fan does not run at a rate where surging may occur.
- (4) Open the damper gradually until the fan reaches the full load operation.
Keep the fan running in this condition for 1 to 3 hours; and check the temperature, vibration, and noise at each section of the fan. In addition, check that the current value of the motor is normal. Pay special attention to blowing of hot air because the current value becomes higher in such a case compared with blowing of air at the room temperature.

The bearing temperature may become slightly higher than usual for about 1 to 2 hours after the start of operation. If there are no errors in the machine, however, the temperature stabilizes afterwards.

- (5) If the blowing gas is hot, thermal expansion after the steady-flow operation may cause misalignment. Therefore, when the temperature has risen enough after the operation, stop the fan and check the alignment.



If the blowing gas is hot, do not touch the fan body, duct, or any other hot parts. Failure to observe this may cause burn on the skin.
In addition, do not place any combustibles around the unit.

4.2.2 Precautions during operation

- (1) Do not start and stop the fan frequently, because it may cause early failure of the fan and motor.

Precautions for test operation and normal operation are as follows.

When starting and stopping the fan repeatedly for a short time during the test operation, keep the starting frequency within the following frequency.

Motor output power	7.5kW or less	11kW - 22kW	30kW or more
Starting frequency	Max. 6 times per hour	Max. 4 times per hour	Max. 3 times per hour

During normal operation, please use the fan for 10 hours of continuous operation per day. If the fan is to be used under conditions where the starting frequency is high, please consult with us.

The expected design life is based on 10-15 years of 10hours of continuous operation per day and 300 operating days per year.

(The expected design life is not a guaranteed value.)



In the event of a power failure, be sure to turn off the main power.
The fan suddenly starts on restoration of the power, and it is very dangerous.



If you leave the fan unused for a long time, be sure to turn off the main power.

4.2.3 Precautions for stopping the operation

- (1) To stop the fan, gradually close the damper to the full and then turn off the power switch.
- (2) If the fan is blowing 200°C or hotter air, close the damper and then keep running the fan for a while. When the inside of the fan has completely cooled down, stop the operation. At that time, ensure that the fan does not run at a rate where surging may occur.

- (3) If the fan is blowing a toxic gas, pay attention to any gas leak from the shaft seal section.



In the event of a power failure, be sure to turn off the main power.
The fan suddenly starts on restoration of the power, and it is very dangerous.

5. Long-term shutdown

5.1 Precautions for long-term shutdown

If you do not use the fan for a long time (1 month or longer), observe the following points:

- (1) If you do not use the fan for a long time, apply appropriate anti-corrosive agent to the areas prone to rust. In addition, refill or change grease to put fresh grease in the bearing.



If you leave the fan unused for a long time, be sure to turn off the main power.

- (2) Take measures to prevent dust or other foreign matter from accumulating on the fan main unit or the motor.
- (3) To prevent the entry of dust or other foreign matter into the connected ducts, close the suction port and the discharge port. If a damper is installed, close the damper.
- (4) Protect the motor and other electrical devices against moisture.
- (5) Detach the V-belt and store it away from high temperature, high humidity, and dusty areas.
- (6) Before you run the fan after a long period of shutdown, inspect each part, and refill or change grease of the bearing.
- (7) Once or twice a month, rotate the impeller shaft by hand and protect the bearing.
- (8) During the long-term shutdown, take measures to keep unauthorized persons away from the fan, for example by installing a barrier or by locking it out.

6. Maintenance and inspection



Warning

Regularly inspect your equipment and perform maintenance on each component.

6.1 Daily inspection

- (1) Check the vibration, noise, current value, or other conditions.
If there is any unusual condition, it may be a sign of failure; therefore, take the appropriate measures as soon as possible.
For this purpose, it is recommended to keep an operation log.




Caution

For APKII, APK5 and APK-B, the main shaft, V-belt pulley, and V-belt are rotating during operation. Be extra careful not to get your clothes etc. caught in these parts.

- (2) If strong vibrations occur, stop operation and inspect the V-belt alignment, duct connections, tightening of the installation bolts and foundation bolts, and check for accumulation of dust on the impeller and damage to the bearings.
If the vibration is within the region specified as "Acceptable" in JIS B 8330, you can run the fan, although the vibration level is preferable in the region specified as "Good" (see Figure 11). Note that, if your fan comes with a vibration isolation device, the vibration is not transmitted to the foundations, but vibration of the fan itself becomes somewhat stronger. In such a case, a vibration lower than the broken line is considered normal.
- (3) In addition to vibrations, noise is an important factor in judging the operating condition.
If you hear a metallic sound possibly made by contact into the rotor, stop the operation immediately.
- (4) Bearings generate noise even in normal condition.

Although it is difficult to identify an abnormal noise because bearings produce complicated noise, try and detect it at an early stage with careful attention.



Normal noise produced at bearings

Type of noise	Normal noise
Raceway noise	A constant hissing noise. This noise is generated when a ball rolls on the raceway surface.
Roller falling noise	Clattering sound. When load is applied in the radial direction (which is the case for most fans), the balls are alternately loaded and unloaded. Noise is produced at the switching point of loaded/unloaded state. It occurs mostly with low speed rotation.
Retainer noise	A retainer maintains the relative position of the balls. There is a small gap between the retainer and the outer ring, which allows the retainer to rotate; however, a continuous chunking noise is generated when the retainer is occasionally in contact with the outer ring. It is a slightly annoying noise, but cannot be eliminated easily. It occurs mostly with low speed rotation.

Abnormal noise produced at bearings

Type of noise	Abnormal noise
Contamination noise	Foreign matter could get into a bearing through careless handling of grease or for other reasons. In such a case, the bearing makes an irregular grinding noise. Replace with new grease.
Flaw noise	Any flaws on the bearing generate a discontinuous irregular noise. Any flaws on the raceway surface of the inner or outer ring generate a continuous noise. If the noise is faint or insignificant, the bearing may still be used after being refilled with grease. If the noise becomes serious, replace the part.
Rust noise	It is the same type of noise as "Noise caused by flaw." If the noise becomes serious, replace the bearing.
Squeaking noise	It is a squeaking noise without a regular cycle. This noise is generated when a slip occurs between the ball and raceway or between the ball and retainer or when lubrication is not effective. Replace with high-quality grease.

6.2 Periodic inspection

 Warning 
If motors or control panels are used for more than a certain period of time, it may cause ignition or other accidents due to aging deterioration.
 Warning 
Before carrying out the inspection of the fan, be sure to turn off the main power. Otherwise the fan may suddenly start up during automatic operation or from other causes, and it is very dangerous.

Carry out the periodic inspection at least once a year.

The periodic inspection items include the following points, in addition to the daily inspection items.

- (1) Greasing of bearings or replacement of bearings (APKII, APK5 and APK-B)
- (2) Rechecking of the center alignment and checking of the V-belt (APKII and APK5). Check the V-belt for wear, tear and tension, and if necessary, replace it with new one and re-tension it.
- (3) Check the play between parts.
- (4) Inspect the impeller and the shaft for corrosion and wear.
- (5) Clean the inside of the fan, and apply anti-corrosive agent or otherwise repair the part.
- (6) Check that the insulation resistance of the motor has not decreased. At least 1MΩ is required.

Note
The alignment and belt tension adjustment may peel off the coating in the sliding section around the motor mounting leg, resulting in rusting. If you install the unit in a humid place or outdoors, carry out repair coating in order to prevent rusting.

Periodic inspection items

Part	Inspection item	Inspection method	Acceptance criterion (as a guide)
Entire fan unit	Noise, vibration	Listen, touch	No noise or vibration significantly larger than the initial state.
Casing	Appearance (e.g. corrosion, adhesion, deformation, and leakage)	Visual check	No significant adhesion of dust, deformation, flaws, corrosion, or other problems related to appearance.
	Noise, vibration	Listen, touch	No abnormal noise or vibration.
Impeller	Check the running condition	Visual check (rotating by hand)	No contact or abnormal noise.
	Appearance (e.g. corrosion, adhesion, and deformation)	Visual check	No significant corrosion, deformation, or adhesion.
Main shaft	Appearance (e.g. corrosion, adhesion, deformation, and fit)	Visual check	No color change on the shaft. No rust at the fit.
	Looseness of fixing nuts	With a tool	No looseness
Bearing	Amount of grease	Check the hours of operation.	Grease is periodically applied according to this manual.
	Operation status (noise)	Listen	No abnormal noise.
	Operation status (vibration)	Vibration meter	Refer to the "Acceptable vibration range" shown in Figure 11.
	Surface temperature	Surface thermometer	Not higher than [the ambient temperature +40°C] or [70°C], whichever is lower
	Rotation movement	Touch	Can be rotated by hand smoothly and uniformly.
	Appearance (e.g. corrosion, adhesion and wear)	Visual check	No significant corrosion, wear, or deformation.
	Looseness of screws	With a tool	No looseness
V-belt	Check the tension	Tension meter	The amount of deflection and tension load must comply with the values calculated for each case, or must be within the range specified by the V-belt manufacturer.
	Rattling of the V-belt	Visual check	No significant rattling.
	Alignment of V-belt pulleys	Visual check using a straight ruler or piano wire	The parallelism and eccentricity of the V-belt pulleys must be within 1/3°.
	Appearance, wear, flaws	Visual check	No significant twisting, flaws, or cracks.
V-belt pulley	Appearance, flaws	Visual check	No significant flaws or cracks.
	Wear of the groove	Visual check	The new V-belt must not touch the bottom of the groove. No local wear or left/right partial side wear.
	Wear (fit with the main shaft)	Visual check	No significant wear.
	Looseness of fixing screws	With a tool	No displacement or looseness of the V-belt pulleys.
Belt guard	Appearance	Visual check	No significant rust or deformation.
Motor	Insulation	500 V megger	Insulation resistance must comply with the value specified for the motor.
		Check by smelling	No smell of varnish burning.
	Noise	Listen Auscultation rod	No significant noise. No increase in noise level compared to normal values.
	Vibration	Touch	No significant vibration.
		Vibration meter	No increase in vibration amplitude compared to normal vibration amplitude.
	Temperature	Visual check Surface thermometer	No change in coating color. No abnormal heat generation.
	Current	Measure	The measured value may not exceed the value shown on the motor nameplate.
Vibration-proof device	Smell	Smell	No burning smell.
	Rotation movement	Touch	Can be rotated by hand smoothly.
	Appearance	Visual check	No significant degradation such as cracks. No displacement.

Guidelines for periodic inspection interval and part replacement

The guideline of annual operation hours is 10 (hours/day) × 300 (days/year) = 3,000 (hours/year). In addition, the service life of the fan differs significantly depending on factors such as the operating conditions, the status of installation, and the status of maintenance. If you find any abnormal condition, stop the operation, replace the parts, and make repairs.

Part name	Replacement interval (guide)	Elapsed years														
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Entire fan unit	15 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	Replace the fan unit
Casing	15 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Impeller	15 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Main shaft	10 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Bearing	3 years	○	○	▲	○	○	▲	○	○	▲	◆	○	▲	○	○	
V-belt pulley	5 years	○	○	○	○	▲	○	○	○	○	▲	○	○	○	○	
V-belt	1 year	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	
Belt guard	15 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Motor	10 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Vibration-proof device	15 years	○	○	○	○	○	○	○	○	○	◆	○	○	○	○	
Description of symbols		○: Periodic inspection (including cleaning and adjustment). Replace parts and make repairs based on the inspection results. ▲: Periodic replacement of consumables ◆: Replace parts or time-change parts based on the inspection results (perform overhaul as needed)														

6.2.1 Greasing and replacement of the bearings

- (1) The pillow blocks of APKII, APK5 and APK-B can be used without lubrication, but if an option of externally greasing type bearings is selected when the fan is ordered, it is recommended to replenish grease at periodic maintenance times to extend the service life.
- (2) Frequency of greasing and amount of grease are indicated in the table below. Be careful not to replenish an excessive amount of grease.
- (3) The grease to be used is Shell Alvania Grease NO.3.
When the heat resistant pillow blocks (HR5 clearance) are used for a special purpose, the grease to be used is Yuken Kogyo's Super Lube NO.3.
Do not mix different types of greases.
- (4) The use of the fan in dusty or somewhat moist environment should be avoided, but if it is unavoidable, increase the frequency of greasing or replacement.
- (5) Replenish grease via the grease nipple using a grease pump while the fan is running.

Greasing frequency of pillow blocks			Grease replenishing amount of pillow blocks					
Environment	Bearing temp. (°C)	Frequency	Bearing No.	Amount g	Bearing No.	Amount g	Bearing No.	Amount g
Clean	50°C or lower	1-12 months	UCP204	1.2	UCP214	13.6	UCP314	31.5
Dusty	70°C or lower	1-4 months	UCP205	1.4	UCP216	18.8	UCP315	38
Moist		1 week	UCP206	2.2	UCP306	3.8	UCP316	41
			UCP207	3.2	UCP307	5.7	UCP317	52
			UCP208	3.9	UCP308	7.8	UCP318	62
			UCP209	5	UCP309	9.4	UCP319	73
			UCP210	5.4	UCP310	12.8	UCP320	92
			UCP211	7.4	UCP311	16.4	UCP321	106
			UCP212	10	UCP312	21	UCP322	133
			UCP213	11.8	UCP313	26	UCP324	158

6.2.2 Consumables


Warning


For replacement of parts, repairs, etc., ask TERAL INC.
Incorrect work may cause a failure or an accident.

Refer to the table below for intervals to replace consumables.

Consumable	Condition of replacement (as a guide)	Cycle to replace (as a guide)
Pillow block	Abnormal noise	Once every 3 years
V-belt	Deterioration or wear	Once a year
V-pulley	Wear	Once every 5 years

There are slight differences in length even between V-belts of the same size. Use a V-belt of the same matched set for a single unit of the fan. Do not use a combination of new and old belts. Please use the same consumable parts as shipped for replacement. If you would like to consider changing the type, please contact us.

7. Troubleshooting

7.1 Troubleshooting

The cause of the failure and the corrective measures against it may be different even if the fan shows the same symptom. In addition, there may be two or more causes.

If you cannot find the cause or corrective measures in the following table, immediately stop the operation and contact the vendor or the service center specified by the manufacturer.

Symptom	Cause	Action	Reference page
Bearing temperature is high	Excess or lack of grease	Adjust it to the proper amount.	p.6-4
	Poor fit between the inner ring of a bearing and the shaft	Replace the shaft. Replace the motor.	
	Poor fit between the outer ring and housing of a bearing	Replace the bearing. Replace the motor.	p.6-4
	Deterioration of grease, or entry of moisture	Change the grease. Replace the bearing.	
	Excessive tension of the V-belt	Adjust the tension of the V-belt	p.3-5.3-6
Strong vibration	Foreign matter adhered to the impeller, corrosion, wear	Remove the foreign matter adhered to the impeller. Correct the balance of the impeller.	
	Poor fit between the impeller hub and the shaft	Replace the impeller or shaft (motor).	
	Unbalance of V-belt pulleys	Replace any of the V-belt pulleys or correct the balance.	
	Bending of the shaft	Replace the shaft. Replace the motor.	
	Contact between the rotator and casing	Reassemble the casing.	
	Resonance resulting from poor foundations	Reinforce the foundations.	
Abnormal noise	Poor tightening of mounting bolts	Retighten bolts and nuts.	
	Damage to a bearing	Replace the bearing.	
	Suction of foreign matter	Inspect the inside of the casing.	
	Contact between rotator and casing	Break the contact between the rotor, casing, and suction port.	
	Slipping of the V-belt. Contact with the belt guard	Readjust the V-belt tension. Correct the position of the guard.	p.3-5.3-6
	Low voltage of the main power	Adjust the main power.	
Low performance	Low rotation speed, or low frequency	Adjust the main power.	
	Low voltage of the main power	Adjust the main power.	
	Reverse rotation	Swap the wires of the motor.	p.3-8
	Corrosion or wear in the impeller, or foreign matter on the impeller	Clean, repair, or replace the impeller.	
	Clogging of the suction filter	Clean the suction filter.	p.8-1
	Improper opening/closing of the damper	Repair the damper.	
	Dust accumulated in the casing and duct	Clean the inside.	
	Excessive resistance	Consider installing a booster fan, or replace the V-belt pulley.	
	Errors in the calculation of gas specific gravity	Measure the specific gravity. Analyze the gas.	
Motor overload	Insufficient resistance	Adjust it with the damper.	p.8-1
	Excessive rotation speed (belt drive)	Replace the V-belt pulley.	
	Errors in the calculation of gas specific gravity	Reduce the rotation speed.	
	Low voltage of the main power	Adjust the main power.	

8. Special accessories

8.1 Dampers

- (1) Referring to the dimensional outline drawing that is submitted separately, install the damper in place. At that time, pay attention to the rotation direction of the fan's impeller (see Figure 12).
- (2) If the damper is of an electric or air cylinder type, carefully read the instruction manual of the actuator before use.




Figure 12 – Installation direction of the damper

8.2 Expansion joint

Its face-to-face dimension must comply with the value specified in the dimensional outline drawing. Do not pull or push the joint forcibly. In addition, do not correct the misalignment between the fan and the duct with the expansion joint.

8.3 Filter

Careful consideration must be given to the installation of the filter so that the fan can be disassembled easily, for example by using a short duct. Before installing the filter, thoroughly clean the inside of the fan and duct. The filter tends to clog easily immediately after the start of operation. Therefore, inspect the filter earlier than usual. After that, periodically remove the filter and wash it with water.



Head Office

230, Moriwake, Miyuki-cho, Fukuyama-city, Hiroshima, 720-0003, Japan
Tel.+81-84-955-1111 Fax.+81-84-955-5777

www.teral.net